

GMC TRUCK – SM197 CONVERSION

- 1) Carefully tap the old plastic switch out of the pot metal housing.
- 2) Remove the brass horn contact ring, bearing and horn wire from the old switch.
- 3) Install the above items onto the new SM197 switch, plugging the horn contact terminal into the empty slot on the brown plug.